Equiparc

Version 2 2026-11-10

MAINTENANCE GUIDE

At the beginning of each season, check the stability and levelness of the furniture. Inspect all support and base connections, as well as slat fasteners and ground anchors. Make any necessary adjustments and tighten all connections.

FURNITURE STRUCTURE

Hot-dip galvanized steel (Unpainted):

No maintenance required. If the structure is damaged and the steel is exposed (scratches, etc.), we recommend applying a zinc-based cold galvanizing spray to the affected areas.

Product reference: Spraygalv Bright by Dynaflux Inc.

Painted hot-dip galvanized steel:

If the hot-dip galvanized steel is painted, we recommend performing any necessary paint touch-ups annually.

Product reference: Exterior-grade paints, ensuring that the colours are properly matched.

Stainless steel:

No maintenance required. To clean stainless steel components, we recommend using cleaning products specifically formulated for stainless steel.

Product reference: Cerama Bryte.

Painted zinc-primed steel or painted aluminum:

To preserve the finish, we recommend cleaning these surfaces with mild soap and performing any necessary paint touch-ups annually.

Product reference: Exterior-grade paints, ensuring that the colours are properly matched.

1001, rue James-Brodie
Saint-Jean-sur-Richelieu (Québec) J2X 0C1
Tél. : 450 346-1882 1 800 363-9264
info@equiparc.com | equiparc.com

Equiparc

MAINTENANCE GUIDE (continued…)

FURNITURE SURFACING

Recycled plastic :

No maintenance required. Highly durable, crack-resistant, and splinter-free. Clean with water and regular soap as needed.

Ipe, Jatoba and Kebony wood :

No maintenance is required. The wood will naturally weather to a grey patina over time without losing its physical properties.
Its original appearance can be restored by following these steps:

- Lightly sand the wood and remove all residual dust before applying oil.
- Apply the oil according to the manufacturer's instructions for the selected product.

Product references: Ipe Oil or Messmer's UV Plus for Hardwoods.

Douglas Fir and white Oak:

Apply one or more coats of exterior wood stain every 2 to 3 years, depending on the product used.

- Lightly sand the wood and remove all residual dust before applying the stain.
- Apply the stain according to the manufacturer's instructions. Some products require multiple coats and a specific drying time.
-

Product reference: Sikkens Cetol 1 & Cetol 23 Plus.

General information regarding all wood types

It is normal for cracks to develop and for wood to turn grey over time due to UV exposure.

Air-dried wood naturally adjusts to ambient temperatures and acclimates to its surrounding environment. These natural changes do not affect its structural integrity or physical properties.

For any questions regarding furniture maintenance, please do not hesitate to contact us.

1001, rue James-Brodie
Saint-Jean-sur-Richelieu (Québec) J2X 0C1
Tél. : 450 346-1882 1 800 363-9264
info@equiparc.com | equiparc.com